

SETUP GUIDELINES




GABRIELS[®]

Sentinel



SETUP GUIDELINES

- 1** Turn the levelers out until these protrude around 1 cm below the bottom of the pedestal.
- 2** Install the leveler-plates under the levelers of the pedestals.



2

SETUP GUIDELINES

3 Position the pedestals with 185 – 190 cm between them.




3

SETUP GUIDELINES

4 Install the body panels.




Do NOT tighten the bolts until both body panels are fitted.



SETUP GUIDELINES

5 Install both long frame beams to the pedestals.



Do NOT tighten the bolts yet.





5

SETUP GUIDELINES

6 Install the 4 center supports between the long beams.



Do NOT tighten the bolts yet.



6

SETUP GUIDELINES


7 Install the 2 short beams and tighten the bolts.



Always fit the frame bolts from the outside going inwards



8 Tighten the bolts of the 4 center-supports.

9 Tighten the bolts which connect the pedestals with the legs.




SETUP GUIDELINES

- 10 Fit the levelers in the frame and make sure these are all flush with the recessed part section of the frame.




SETUP GUIDELINES

- 11** Slide the slates in the correct position so that the holes in the frame correspond with those in the slates.




SETUP GUIDELINES

- 12** Fit the cloth as tight as possible.
Cut openings in the cloth corresponding
with the rail bolt holes.




SETUP GUIDELINES


- 13** Insert the rail bolt - nuts in the rail, position them so that the hole lines up with the corresponding marking on the rail. Secure the nuts in place by tightening the set-screws.



- 14** Mount the rail corners on the short rails.





- 15** Fit the short rails fitted with the rail corners to the long rails.



SETUP GUIDELINES

- 16** Install the "Gabriels" pocket liners by means of the Aluminum studs. Make sure the stud fits perfectly in the pocket liner before screwing it tight with the Allen screws.



SETUP GUIDELINES

- 17** Install the 4 casted apron corners on the rail assembly.



Do NOT tighten the bolts yet.

- 18** Install the aluminum apron supports in the rails.




Do NOT tighten the bolts yet.




SETUP GUIDELINES

- 19** Fit the aprons on the rail – assembly by use of the knobs and the sliding nuts in the apron profile. Note there are 2 lengths:
- Long ones are intended for fitting the apron to the aluminum supports
 - Short ones will be used to fit the aprons to the casted apron corners.




- 20** First tighten the bolts of the apron corner to the rail corners, then tighten the bolts of the aluminum supports, and finally tighten the knobs.



SETUP GUIDELINES


- 21** Turn the rail assembly over and place it on the covered slate. Manually insert the rail bolts through the slate into the rail nuts and align the rail assembly. When aligned correctly, the frame bolts can be tightened.
- 22** Install the ball-baskets and fit them to the rails. Check if these are aligned correctly before tightening.



SETUP GUIDELINES

- 23** Check the aprons are clear of dust and install the brand name stickers. Make sure these are level because once installed these are very difficult to remove.





www.gabrielsbilliards.com